



DE'LONGHI

RU SA INT SKA EC200CD

Pos.	Code	Description
	5313270059	HEATING ELEMENT SEAL
001	5332218100	COVER
002	5332169200	MEASURING SPOON
003	5532109300	KNOB
004	5332124400	COVER
006	5118100800	WARNING LIGHT
007	5932109700	CONTROL PANEL
008	6113211791	SPRING
009	5532107500	KNOB
010	ES000	*NOT AVAILABLE
011	511816	FUSE
013	5132108100	Change Over Switch
014	7313278259	TAP
015	5232101300	THERMOSTAT 125
016	5232100600	THERMOSTAT 105
017	536281	TUBE
018	6813210411	BOILER UPPER
019	533216	GASKET
020	5513270609	HEATING Element ASSY
022	6832101000	BOILER LOWER
023	6032101200	DIFFUSER
024	533218	GASKET
025	7032101500	SUPPORT
030	6213210431	CONNECTION
031	6132101300	CLIP
032	5313217701	O-RING D=3,85
033	5513220521	FILTER
034	5332122800	TUBE
035	534848	SUPPORT
036	5113211281	PUMP
037	5532146000	TUBE PTFE DI2-DE4 L=90 2BUSHES
038	7332128100	VALVE
039	5332120300	HINGE
040	536321	TUBE
041	5332125200	TUBE
043	7313275619	TANK
045	5332289700	VALVE

DE'LONGHI**EC 200CD ROSSA****RU SA INT SKA EC200CD**

046	621986	RING
047	6232103400	DOWEL
049	6132101600	SPRING
050	5332124300	SUPPORT
051	5332120500	SPACER
052	535733	JOINT
053	5332120200	STOP
054	5332120700	BLOCK
055	535789	FROTHER
056	5332117200	PRESSING DEVICE
057	6113210481	TUBE DISTRIBUTING
058	5332120400	CUP PLATE
059	5332120000	TRAY
060	532233	RUBBER PAD
062	534714	LEVER
063	5532113400	BOTTOM
064	9824800009	CLIP CLAMP
065	5532109500	BODY
066	5332108700	GASKET
066	5332108700	GASKET
067	5332109000	PISTON
068	6132100800	SPRING
069	5332111600	O-RING
070	7332173100	SUMP
071	5332123100	RING NUT
072	6032102400	FILTER
073	5532108700	FROTH DISPENSER
074	5332117600	GASKET
075	7332122300	FILTER HOLDER PODS UNIVERSAL