



**DE'LONGHI****EC270****RU INT SKA EC270**

Pos.	Code	Description
001	7013210021	COVER
002	5313210231	PROTECTION
003	5913210081	PUSH BUTTON LEFT
004	5913210071	PUSH BUTTON
005	5913210061	PUSH BUTTON RIGHT
006	5313210241	SUPPORT
007	5313210171	SWITCH HOLDER
008	IT0192	SEE TECHNICAL INFORMATION
009	5132100700	SWITCH
010	5313210331	SPACER
013	5313210341	SPACER
014	5313210271	DUCT
015	7013210011	CUP PLATE
016	5332266600	FLOAT
017	5313210261	BLACK TRAY
018	IT0192	SEE TECHNICAL INFORMATION
019	532233	RUBBER PAD
020	5013272679	POWER SUPPLY CORD
023	7313280769	FILTER HOLDER
024	5313210161	LEVER
026	7313275099	Small one-cup or pod filter
027	7313275109	Large two-cup filter
027	7313275109	Large two-cup filter
028	5332125200	TUBE
028	5332125200	TUBE
029	5513220521	FILTER
029	5513220521	FILTER
030	IT0192	SEE TECHNICAL INFORMATION
030	IT0192	SEE TECHNICAL INFORMATION
033	534848	SUPPORT
033	534848	SUPPORT
034	534213	FOOT
034	534213	FOOT
035	5113211281	PUMP
035	5113211281	PUMP
036	7332128100	VALVE
036	7332128100	VALVE

**DE'LONGHI****EC270****RU INT SKA EC270**

037	6132101300	CLIP
037	6132101300	CLIP
038	5532112000	TUBE
038	5532112000	TUBE
040	5332159400	BUSH
040	5332159400	BUSH
043	5332108700	GASKET
043	5332108700	GASKET
043	5332108700	GASKET
043	5332108700	GASKET
044	5332109000	PISTON
044	5332109000	PISTON
045	6132100800	SPRING
045	6132100800	SPRING
046	5332173500	O-RING
046	5332173500	O-RING
047	5313210121	HINGE UPPER
047	5313210121	HINGE UPPER
048	5313210111	COVER
048	5313210111	COVER
049	7313282109	TANK
049	7313282109	TANK
050	7313277889	KNOB
050	7313277889	KNOB
053	511816	FUSE
053	511816	FUSE
054	607529	BRACKET
054	607529	BRACKET
055	5232101300	THERMOSTAT 125
055	5232101300	THERMOSTAT 125
056	5232100600	THERMOSTAT 105
056	5232100600	THERMOSTAT 105
057	5513270609	HEATING Element ASSY
057	5513270609	HEATING Element ASSY
058	533216	GASKET
058	533216	GASKET
059	6813210421	BOILER
059	6813210421	BOILER

**DE'LONGHI****EC270****RU INT SKA EC270**

060	535693	GASKET
060	535693	GASKET
062	5332148400	VALVE
062	5332148400	VALVE
063	6132101600	SPRING
063	6132101600	SPRING
064	7313270759	SUPPORT
064	7313270759	SUPPORT
065	5332140900	GASKET
065	5332140900	GASKET
066	6032107100	DIFFUSER
066	6032107100	DIFFUSER
067	5313210051	MEASURING SPOON
067	5313210051	MEASURING SPOON
068	5532154000	TUBE DISTRIBUTING
068	5532154000	TUBE DISTRIBUTING
069	5332169300	TUBE LOWER
069	5332169300	TUBE LOWER
070	5313217751	O-RING
070	5313217751	O-RING
071	5513270409	FROTHER
071	5513270409	FROTHER
072	535733	JOINT
072	535733	JOINT
073	531533	TUBE RETAINER
073	531533	TUBE RETAINER
074	5313210091	STOP
074	5313210091	STOP
075	5313210071	REAR PANEL
075	5313210071	REAR PANEL
076	6213210451	DOWEL
076	6213210451	DOWEL
077	621986	RING
077	621986	RING
078	6813210411	BOILER UPPER
078	6813210411	BOILER UPPER
079	9850081500	WASHER
079	9850081500	WASHER

**DE'LONGHI****EC270****RU INT SKA EC270**

080	6213210431	CONNECTION
080	6213210431	CONNECTION
081	5313217701	O-RING D=3,85
081	5313217701	O-RING D=3,85
082	534710	GASKET
082	534710	GASKET
083	7313281449	VALVE
083	7313281449	VALVE
084	5313223221	O-RING
084	5313223221	O-RING
085	5332144800	O-RING D=6
085	5332144800	O-RING D=6
086	7313278849	TAP
086	7313278849	TAP